


General Processes/Information

Update barcode scanner (PT BS-041 only) setting to scan UPCA/EAN13 barcodes


Scan the first barcode to: ENTER SETUP



#SETUPE1

启动设置

Scan this to update the setting:



@UPAPRE1

** 【传送系统字符】

and then finally scan the last barcode to exit the setup:

General Processes/Information



#SETUPE0

退出设置

Unique solution ID: #1155
Author: Mary Nicole Quirabu
Last update: 2022-05-27 11:13